

- Long press any of these switches 'DC/USB/AC' to power outputs, long press the output switch again to turn the outputs off.
- An icon will also appear in the display screen to show its been turned on and it will disappear when its turned off.

Charging:

• Using the supplied AC or Vehicle charger, connect to suitable supply and switch on, the AC adaptor LED light will illuminate green to show connection.

• The display screen will show the input, battery level and status.



selected

Battery level and status

IMPORTANT SAFETY INFORMATION:-

· Never submerge in water.

- If you suspect the unit has water inside, do not use or attempt to recharge.
- Dropping the Generator may damage the battery or circuit components inside.
- IF THE GENERATOR HAS BEEN SUBMERGED IN WATER OR SUSTAINED DAMAGE IT COULD BE A FIRE HAZARD. DO NOT USE THE PRODUCT.
- Place outdoors in a non-combustible container well away from flammable materials. DO NOT RECHARGE THE BATTERY AND CONTACT NIGHTSEARCHER.
- Place the generator outdoors in a non-combustible container well away from flammable materials and contact: www.nightsearcher.co.uk /+44 (0)2392 389774.
- Always recharge the battery on a hard, flat, heat resistant surface.
- · Battery pack will not reach optimum performance until 4-5 charging cycles
- Avoid charging the battery in temperatures below 0°C or exposing the battery to temperatures below -5°C or above 40°C.
- Never use the charger if the leads, contacts or casings are damaged. Do not use any chargers other than those provided.
- · Never expose the charger to rain, moisture or damp. If you suspect any of these have occurred then do not use the charger.
- · Always check with your airline before attempting to transport by air.
- Do not shine the light directly into people's eyes, as it may damage their eyesight.
- · Keep out of reach of children.
- In case of any problems or questions please contact NightSearcher Limited or an authorised distributor.

If at any time, you need to dispose of this product or parts of this product: please note that waste electrical products, bulbs and batteries should not be disposed of with ordinary household waste. Recycle where facilities exist. Check with your local authority for recycling advice. Alternatively, NightSearcher is happy to take receipt of this product at end-of-life and will recycle it on your behalf.



ĽK 🕱 C € 🚽

NightSearcher Limited Unit 4 Applied House, Fitzherbert Spur, Farlington, Portsmouth, Hampshire, PO6 1TT, UK T: +44 (0)23 9238 9774 E: sales@nightsearcher.co.uk W: nightsearcher.co.uk All NightSearcher products have a 3 year standard warranty on all manufacturing defects and a 1 year warranty on all rechargeable batteries from the date of purchase.

For extended 5 year warranty please visit https://nightsearcher.co.uk/en/extended-warranty.html proof of purchase is required.

Product weight	5kg
Product size	241x161x181mm
NS Part No.	GENZERO-500W-230V