




Supplied with: Fast Charging Type C USB Cable, and shoulder strap.




Charging:



Battery Status and Charging Indicators

Charging Options:



Operating:
Power/Light Mode Switches



Searchlight:
Low → High → OFF
Double click switch → Strobe → OFF

Dimmable:
In High or Low light mode, press and hold the power button for dimmer mode. The light will flash twice when its reached the lowest/highest point.

Floodlight:
Low → High → Red → OFF
Double click switch in Off, Low or High modes → Strobe → OFF
Double click switch in Red mode → Red Flashing → OFF

Dimmable:
In High/Low/Red light mode, press and hold the power button for dimmer mode. The light will flash twice when its reached the lowest/highest point.

Multi directional floodlight



NightSearcher Limited
Unit 4 Applied House, Fitzherbert Spur, Farlington,
Portsmouth, Hampshire, PO6 1TT, UK
T: +44 (0)23 9238 9774 | E: sales@nightsearcher.co.uk

If at any time, you need to dispose of this product or parts of this product: please note that waste electrical products, bulbs and batteries should not be disposed of with ordinary household waste. Recycle where facilities exist. Check with your local authority for recycling advice. Alternatively, NightSearcher is happy to take receipt of this product at end-of-life and will recycle it on your behalf

All NightSearcher products have a 3-year standard warranty on all manufacturing defects and 1-year warranty on all rechargeable batteries from the date of purchase. Please visit www.nightsearcher.co.uk for extended warranty information, proof of purchase is required.



Product weight (g)	708g
Product size (mm)	213x132x106mm
NS Part No.	NSCOBRA-X