## 🐼 NightSearcher Zoom 700 - User manual




Supplied with head strap, 3 x AAA batteries

## Insert batteries:



Lift the open launch on top of the head torch and pull open the battery compartment. Insert 3 x AAA alkaline batteries into the battery compartment.



All NightSearcher products have a 3-year standard warranty on all manufacturing defects and 1-year warranty on all rechargeable batteries from the date of purchase. For extended 5 year warranty please visit https://nightsearcher.co.uk/en/extended-warranty.html proof of purchase is required.

If at any time, you need to dispose of this product or parts of this product: please note that waste electrical products, bulbs and batteries should not be disposed of with ordinary household waste. Recycle where facilities exist. Check with your local authority for recycling advice. Alternatively, NightSearcher is happy to take receipt of this product at end-of-life and will recycle it on your behalf.



E: sales@nightsearcher.co.uk

Product weight (g)	94g (with batteries)
Product size (mm)	62x41X43mm
NS Part No.	NSHTZOOM700